NSD ARCHITECTURE DAY05

1. <u>案例1: 安装Hadoop</u> 2. <u>案例2: 安装配置Hadoop</u>

1 案例1:安装Hadoop

1.1 问题

本案例要求安装单机模式Hadoop:

- 单机模式安装Hadoop
- 安装JAVA环境
- 设置环境变量,启动运行

1.2 步骤

实现此案例需要按照如下步骤进行。

步骤一:环境准备

1)配置主机名为nn01, ip为192.168.1.21,配置yum源(系统源)

备注:由于在之前的案例中这些都已经做过,这里不再重复,不会的学员可以参考之前的案例

2) 安装java环境

- 01. [root@nn01~] # y um y install jav a- 1.8.0 openjdk- dev el
- 02. $[root@nn01 \sim] # java version$
- 03. openjdk version "1.8.0_131"
- 04. OpenJDK Runtime Environment (build 1.8.0 131-b12)
- 05. OpenJDK 64- Bit Server VM (build 25.131- b12, mixed mode)
- 06. [root@nn01~]#jps
- 07. 1235 Jps

3)安装hadoop

- 01. [root@nn01~] #tar xf hadoop- 2.7.6.tar.gz
- 02. [root@nn01~] # mv hadoop- 2.7.6 /usr/local/hadoop
- 03. [root@nn01~] # cd /usr/local/hadoop/
- 04. [root@nn01 hadoop] # Is
- 05. bin include libexec NOTICE.txt sbin
- 06. etc lib LICENSE.txt README.txt share
- 07. [root@nn01 hadoop] # ./bin/hadoop //报错, JAVA_HONE没有找到
- 08. Error: JAVA_HOME is not set and could not be found.

09. [root@nn01 hadoop] #

4)解决报错问题

```
01.
       [root@nn01 hadoop] # rpm - ql jav a- 1.8.0- openjdk
02.
       [root@nn01 hadoop] # cd ./etc/hadoop/
03.
       [root@nn01 hadoop] # v im hadoop- env.sh
04.
       25 export \
05.
       JAVA HOME="/usr/lib/jvm/java-1.8.0-openjdk-1.8.0.131-11.b12.el7.x86 64/jre"
06.
07.
       33 export HA DOOP_CONF_DIR="/usr/local/hadoop/etc/hadoop"
08.
       [root@nn01~] # cd /usr/local/hadoop/
09.
       [root@nnO1 hadoop] # ./bin/hadoop
10.
       Usage: hadoop [--config confdir] [ COMMAND | CLASSNAME]
11.
        CLASSNAME
                           run the class named CLASSNAME
12.
       or
13.
        where COMMAND is one of:
14.
        fs
                      run a generic filesy stem user client
15.
        version
                        print the version
16.
        jar ⊲jar>
                        run a jar file
17.
                      note: please use "y arn jar" to launch
18.
                          YARN applications, not this command.
19.
        checknative [-a|-h] check native hadoop and compression libraries availability
20.
        distcp <srcurl> <desturl> copy file or directories recursively
21.
        archive - archiveName NAME - p <parent path> <src>* <dest> create a hadoop archive
22.
        classpath
                         prints the class path needed to get the
23.
        credential
                         interact with credential providers
24.
                      Hadoop jar and the required libraries
25.
        daemonlog
                          get/set the log level for each daemon
26.
        trace
                       view and modify Hadoop tracing settings
27.
28.
       Most commands print help when invoked w/o parameters.
29.
30.
       [root@nn01 hadoop] # mkdir /usr/local/hadoop/aa
31.
       [root@nn01 hadoop] # Is
32.
       bin etc include lib libexec LICENSE.txt NOTICE.txt aa README.txt sbin share
33.
       [ root@nn01 hadoop] # cp *.txt /usr/local/hadoop/aa
34.
       [ root@nn01 hadoop] # ./bin/hadoop jar \
                                                                                 Top
35.
       share/hadoop/mapreduce/hadoop-mapreduce-examples-2.7.6.jar wordcount aa bb
36.
       [root@nn01 hadoop] # cat bb/part-r-00000 //查看
```

2 案例2:安装配置Hadoop

2.1 问题

本案例要求:

- 另备三台虚拟机,安装Hadoop
- 使所有节点能够ping通,配置SSH信任关系
- 节点验证

2.2 方案

准备四台虚拟机,由于之前已经准备过一台,所以只需再准备三台新的虚拟机即可,安装 hadoop,使所有节点可以ping通,配置SSH信任关系,如图-1所示:

主机	角色	软件
192.168.1.21 nn01	NameNode SecondaryNameNode	HDFS
192.168.1.22 node1	DataNode	HDFS
192.168.1.23 node2	DataNode	HDFS
192.168.1.24 node3	DataNode	HDFS

图-1

2.3 步骤

实现此案例需要按照如下步骤进行。

步骤一:环境准备

- 1)三台机器配置主机名为node1、node2、node3,配置ip地址(ip如图-1所示),yum源(系统源)
 - 2)编辑/etc/hosts(四台主机同样操作,以nn01为例)

01. [root@nn01~] # vim /etc/hosts

02. 192.168.1.21 nn01

03. 192.168.1.22 node1

04. 192.168.1.23 node2

05. 192.168.1.24 node3

Top

3)安装java环境,在node1,node2,node3上面操作(以node1为例)

01. [root@node1~] # y um - y install jav a- 1.8.0- openjdk- dev el

4)布置SSH信任关系

```
01.
      [root@nn01~]#vim/etc/ssh/ssh config //第一次登陆不需要输入ves
02.
      Host *
03.
           GSSAPIA uthentication yes
04.
           StrictHostKey Checking no
05.
      [root@nn01.ssh] # ssh- key gen
06.
      Generating public/private rsa key pair.
07.
      Enter file in which to save the key (/root/.ssh/id_rsa):
08.
      Enter passphrase (empty for no passphrase):
09.
      Enter same passphrase again:
10.
      Your identification has been saved in /root/.ssh/id_rsa.
11.
      Your public key has been saved in /root/.ssh/id_rsa.pub.
12.
      The key fingerprint is:
13.
      SHA 256: Ucl8OCezw92aArY5+zPtOrJ9ol1ojRE3EAZ1mgndYQMroot@nn01
14.
      The key's randomart image is:
15.
      +--[RSA 2048]---+
           o*E*=.
16.
17.
            +XB+.
18.
            ..=Oo.
19.
            0.+0...
20.
           .S+.. o
21.
           +.=0
22.
           0+00
23.
            0+=.0
24.
            o=0.
25.
      +---[SHA 256]----+
26.
      [root@nn01.ssh] # for i in 21 22 23 24; do ssh-copy-id 192.168.1.$i; done
27.
      //部署公钥给nn01, node1, node2, node3
```

5)测试信任关系

```
    01. [root@nn01.ssh] # ssh node1
    02. Last login: Fri Sep 7 16: 52: 00 2018 from 192.168.1.21
    03. [root@node1~] # exit
    04. logout
```

```
05. Connection to node1 closed.
06. [root@nn01.ssh] # ssh node2
07. Last login: Fri Sep 7 16: 52: 05 2018 from 192.168.1.21
08. [root@node2 ~] # exit
09. logout
10. Connection to node2 closed.
```

[root@nn01.ssh] # ssh node3

步骤二:配置hadoop

1)修改slaves文件

11.

```
01. [root@nn01~] # cd /usr/local/hadoop/etc/hadoop
02. [root@nn01 hadoop] # v im slav es
03. node1
04. node2
05. node3
```

2) hadoop的核心配置文件core-site

```
01.
      [root@nn01 hadoop] # v im core-site.xml
02.
      <conf iguration>
03.
      property>
04.
           <name>f s. def aultFS</name>
05.
           <v alue>hdf s: //nn01: 9000
06.
         </property>
07.
         property>
08.
           <name>hadoop.tmp.dir
09.
           <v alue>/v ar/hadoop</v alue>
10.
         </property>
11.
      </configuration>
12.
13.
      [ root@nn01 hadoop] # mkdir /var/hadoop
                                                 //hadoop的数据根目录
14.
      [root@nn01 hadoop] # ssh node1 mkdir /v ar/hadoop
15.
      [root@nn01 hadoop] # ssh node2 mkdir /var/hadoop
16.
      [root@nn01 hadoop] # ssh node3 mkdir /var/hadoop
```

Top

3)配置hdfs-site文件

```
01.
      [root@nn01 hadoop] # v im hdf s- site.xml
02.
       <configuration>
03.
       property>
04.
            <name>df s. namenode. http- address
05.
            <v alue>nn01: 50070
06.
         </property>
07.
         property>
08.
            <name>df s. namenode. secondary . http- address/name>
09.
            <v alue>nn01: 50090</v alue>
10.
         </property>
11.
         property>
12.
           <name>df s. replication</name>
13.
            <v alue>2</v alue>
14.
         </property>
15.
       </configuration>
```

4)同步配置到node1, node2, node3

```
01. [root@nn01 hadoop] # y um - y install rsync //同步的主机都要安装rsync
02. [root@nn01 hadoop] # for i in 22 23 24; do rsync - aSH - - delete /usr/local/hadoop/
03. \ 192.168.1 $i: /usr/local/hadoop/ - e 'ssh' & done
04. [1] 23260
05. [2] 23261
06. [3] 23262
```

5) 查看是否同步成功

```
01.
       [root@nn01hadoop] # ssh node1 ls /usr/local/hadoop/
02.
       bin
03.
       etc
04.
       include
05.
       lib
06.
       libexec
07.
       LICENSE.txt
08.
       NOTICE.txt
09.
       bb
                                                                                   Top
10.
       README.txt
11.
       sbin
12.
       share
```

- 13. aa
- 14. [root@nn01 hadoop] # ssh node2 ls /usr/local/hadoop/
- 15. bin
- 16. etc
- 17. include
- 18. lib
- 19. libexec
- 20. LICENSE.txt
- 21. NOTICE txt
- 22. bb
- 23. README.txt
- 24. sbin
- 25. share
- 26. aa
- 27. [root@nn01 hadoop] # ssh node3 ls /usr/local/hadoop/
- 28. bin
- 29. etc
- 30. include
- 31. lib
- 32. libexec
- 33. LICENSE.txt
- 34. NOTICE.txt
- 35. bb
- 36. README.txt
- 37. sbin
- 38. share
- 39. aa

步骤三:格式化

- 01. [root@nn01 hadoop] # cd /usr/local/hadoop/
- 02. [root@nn01 hadoop] # ./bin/hdfs namenode format //格式化 namenode
- 03. [root@nn01 hadoop] # ./sbin/start- df s.sh //启动
- 04. [root@nn01 hadoop] # jps //验证角色
- 05. 23408 NameNode
- 06. 23700 Jps
- 07. 23591 Secondary NameNode
- 08. [root@nn01 hadoop] #./bin/hdfs dfsadmin report //查看集群是否组建成功
- 09. Live datanodes (3): //有三个角色成功

Top